



INSTALLATION MANUAL FLARM COLLISION WARNING UNIT

Status

Software Version 5.00 (March 01, 2011)

This is a translation of the German manual.

© 2003-2011 FLARM Technology GmbH
Baar-Switzerland
www.flarm.com
info@flarm.com

1. Welcome to the FLARM user community

Thank you for purchasing FLARM, a modern low-cost collision-warning unit for sailplanes and light aircraft. The main task for FLARM is to support the pilot, while he scans the airspace ahead with his own eyes. FLARM is simple to use and does not distract the pilot from the main business in hand.

 Sport flying is an activity that is associated with considerable risks for crew, passengers, third parties and other objects. **In order to make full and safe use of FLARM, it is absolutely essential to be fully aware of the risks, operating conditions, restrictions and limitations associated with the use of FLARM, ensure a proper installation and do regular software updates. This includes familiarity with and observance of the Operating Manual and the Installation Manual.** Additional configuration information can be found in the 'Data Port Specifications' document, e.g. how to suppress additional data at the serial port what might be required in international championships.

We always welcome suggestions for the improvement of FLARM.

The latest version of this handbook and other related documents can be found at the Website www.flarm.com. This Website also has answers to Frequently Asked Questions.

This Website also carries announcements when new software versions or functions are available. If you enter your name on the mailing list, you will automatically receive notification of changes as and when they happen: https://lists.flarm.com/mailman/listinfo/user-list_flarm.com

 Software-Versions 5.x must not be used after March 01, 2015. Before this date, you must update the device in order to use it in the air. An update with the same functionality can be downloaded free of charge. Users will be able to load the software with the aid of a suitable power supply/data cable (not supplied). This operation requires the user to have the unit Fabrication Number (printed on the lower side of the unit) to hand. Software validity has to be time-limited to ensure that all FLARM units are mutually compatible and updates include the latest obstacle data.

2. How it works

FLARM receives position and movement information from an internal 16 channel GPS receiver with an external antenna. A pressure sensor¹ further enhances the accuracy of position measurements. The predicted flight path of a first aircraft - in which FLARM is installed - is calculated by FLARM and the information transmitted by radio, as a low power digital burst signal at one-second intervals. Provided they are within receiving range these signals are almost at the same time received by further aircraft also equipped with FLARM. The incoming signal is compared with the flight path calculated and predicted for the second aircraft. At the same time, FLARM compares the predicted flight path with known obstacle data, including electric power lines, radio masts and cable cars.

If FLARM determines the risk of dangerous proximity to one or more aircraft or obstacles, the unit gives the pilot warning of the greatest danger at that moment. The warning is given by a whistle sound (beep) and bright light emitting diodes (LED). The display also gives indication of the threat level, plus the horizontal and vertical¹ bearing to the threat.

The operating range is very dependent upon the antenna installation in the aircraft. The normal range is about 2 km, but up to 5 km may be achieved in individual cases. The effective range can easily be verified with an online tool².

The GPS and collision coordinates of the other aircraft can also be made available for use in other systems (e.g. external display, speech synthesizer, PDA) via a serial data output. There are a number of manufacturers for such equipment.

¹ Requires Hardware Version 2 or higher. However, the vertical bearing on the serial data output is also available to third-party equipment on Hardware Version 1.

² www.flarm.com/support/analyze

In addition, FLARM operates as an IGC-file compatible flight recorder including the G-record. FLARM is optionally also available as diamond-level IGC-*approved* Flight Recorder, optionally with Engine Noise Level sensor (ENL). FLARM applies for the radio communication between the units a proprietary patent- and copyright-protected protocol. It is not public, but FLARM Technology offers a license contract where it is accessible in the form of a compatible core design ready for integration into 3rd party systems. These systems are officially declared as FLARM-compatible. Any non-licensed use, dissemination, copying, implementation or reverse engineering of the FLARM radio communication protocol, the FLARM hardware and software or parts of it is forbidden by law and will be prosecuted. FLARM is a registered trademark and can not be used without license.



3. General Advice on Installation

Installation and operation must be on the basis of non-interference with and no hazard to the existing suite of other certified equipment necessary for safe flying operation, or installed to comply with official requirements. Installation and operation must comply with official regulations and requirements. When FLARM is permanently installed in an aircraft in Switzerland, the installation must comply with the 'Installation Policy' published by the Swiss Civil Aviation Authority (FOCA). In Germany, an installation as portable device is possible in gliders and motor-gliders; if an installation in powered aircraft is considered, European Commission Regulation (EC) No 1702/2003 must be respected. Note that EASA has defined FLARM-type devices as standard devices for gliders and powered gliders³.

FLARM must be secured in such a position that the pilot has the display LEDs in direct view, and can hear the acoustic warning tone and operate the control buttons. FLARM must not obstruct the piloting operation (incl. emergency procedures, canopy-jettison and pilot bail-out) and in particular it must not hinder his field of view. These requirements must be maintained at all times during conditions of strong turbulence and acceleration. FLARM is not suited for use in conjunction with night vision systems, night flying (no dimmers) or in pressurised cabins.

Ideally, FLARM will be installed under the instrument panel on the central console or on the cockpit sidewall. If the internal display is used, then the rear face (cable connectors) of FLARM must face in the direction of flight. If FLARM is also equipped with an external display and operating unit, then it may be installed elsewhere and another orientation. Usually, such an installation requires an external radio antenna.

The installation must ensure that the internal radio antenna is properly screwed down, standing free and unbent, i.e. that it does not touch other objects which might channel through electrostatic discharges on a regular base. As an example, the internal radio antenna must not have a permanent contact with the cockpit Plexiglas cover otherwise the radio transceiver in FLARM can be damaged.

It is usually best to install FLARM in such a position that the power/data-socket and the microSD-card reader are easily reached from a PC with an extension cable. This simplifies downloading the latest obstacle data and software, and configuring the unit. When updating software, the user must know the unique FLARM unit Fabrication Number.

If possible, FLARM should be so installed that the pilot does not inadvertently touch the push-button during cockpit ingress and egress. If FLARM or components of it are connected to a part of the aircraft which must be dropped in case of emergency, predetermined breaking point must be created in order not to hinder the dropping.

Cables must not be bent or under stress. The installation must allow adequate space for cable connectors and the internal antenna. Power and data cables as well as cables to external displays and other devices must be shortened, i.e. they must not be coiled to avoid inductive effects. Only operate one FLARM per aircraft.

³ EASA decisions No 2006/13/R and 2006/14/R from Dec 20, 2006.

FLARM, the radio antenna (if the internal antenna is not used) and the GPS antenna should each be installed at least 25 cm away from the magnetic compass, more if possible.

After installation, an appropriate entry should be made in the aircraft technical logs and a check made that the installation is in no way detrimental to the performance of mechanical, electrical or magnetic (e.g. compass) performance of other aircraft systems (e.g. radio). The unit serial number and software version should be recorded in the aircraft technical log. In the case of a permanent installation, the 'Means of Compliance' should be confirmed in the aircraft technical log, and an 'AFM Supplement' carried in the aircraft.

4. Configuration through microSD card⁴

If at power up a file named `flarmcfg.txt` is detected on the microSD card, it will be processed as configuration commands. The syntax is the same as on the serial data port (see 'FLARM Data Port Specifications' manual), except for `PFLAC`, `, ID`. This feature is especially useful for batch configuration or a pilot's individual configuration for shared aircraft.

5. Housing

The lower face of the polycarbonate housing has two threads, so that FLARM can easily be secured by two M5 screws (no more than 12 mm long). This thread is in widespread use. FLARM should be installed on a flat surface so that the housing is not subject to any mechanical stress. Alternatively, the unit may be secured by the housing upper face.

The housing can be repeatedly fitted and removed using the DualLock[®] supplied with the unit. The unit comes supplied with two self-adhesive 12.5x25 mm fixtures. Care should be taken to ensure that the bonding strength is very strong on both halves and difficult to detach.

The housing lower face also has two Phillips screws holding the two halves of the housing together. These screws must not be over-tightened. By opening the housing, all guarantees relating to the equipment become null and void. Never ever open the IGC-version.


The housing upper face is not sealed and care should be taken not to allow ingress of solid particles or liquids. Should the unit become humid, it must be thoroughly dried prior to use. Wet devices can be damaged permanently. Condensation may occur if the unit is subjected to sudden massive cooling. The housing should only be cleaned with a slightly moist non-abrasive cloth without any cleaning agents. The housing can be damaged by scratches and abrasion.

The plastic housing is black to minimise glare and has been tested at temperatures from -10 °C to +60 °C and should be protected from excessive direct or indirect solar heating. Even if not subject to mechanical stress, the housing may be deformed at temperatures upwards of +84 °C, and can also be deformed at lower temperatures in the presence of mechanical stress. The unit should not be exposed to strong locally focused solar radiation. Care should be taken when the cockpit canopy is open (lens effect fire hazard).

⁴ Requires Hardware Version 3 or higher.

6. Connectors

The red rear face has an MCX socket for an active GPS antenna, an RJ45 power/data socket and an RJ12 extension socket.



7. Power / Data

The eight-pin RJ45 power/data socket accepts an eight-pin connector (if necessary, a six-pin connector) which is locked in place. The pin connections are generally² in-line with those set out in IGC GNSS FR Specifications⁵, so that the same cables may be used both in the air and on the ground, as used for modern IGC compatible flight data recorders. The key to the connections is defined by the sequence from left to right, not the numbering⁶:


1. +8 to +26 VDC (recommended +12 VDC), linked with Pin 2 inside the unit
2. +8 to +26 VDC (recommended +12 VDC), linked with Pin 1 inside the unit
3. FLARM supplies +3 VDC⁷
4. GND, with Pin 7 and 8 linked to the unit
5. Tx = FLARM transmits data (PC-side to SUB-D9 Pin 2)
6. Rx = FLARM receives data (PC-side to SUB-D9 Pin 3)
7. GND ('negative'), linked with Pin 8 inside the unit (PC-side to SUB-D9 Pin 5)
8. GND ('negative'), linked with Pin 7 inside the unit

During flight operations at least Pins 2 and 7 must be connected. An 8-pole (or if necessary 6-pole) ribbon cable with an RJ45 push-fit connector, or an 8-pole twisted-pair patch cable with RJ45 adapter, are equally suitable. A suitable patch cable open at one end is supplied with FLARM unit⁸ and must be configured to the aircraft connector in the aircraft. When using an 8-pole cable, Pins 1=2 must be joined. Likewise Pins 7=8. If the remaining wires are not used, they must be individually insulated and must not be soldered or twisted together -- not even in pairs.


There must be a direct electrical connection between FLARM and the aircraft battery. This connection *must* be via a 500 mA fuse. Essential electrically-operated flight instruments must not draw their power through FLARM fuse. It must be possible for the pilot to interrupt the power supply to FLARM during flight by means of a switch or circuit breaker without affecting other essential aircraft systems. This might be necessary if the pilot suspects that FLARM may be interfering with another on-board system, the suspected presence of smoke, the smell of smoke, or flying in a country where the use of FLARM is not permitted.



In spite of reverse polarity protection, it is important to check for correct polarity during installation; in particular the power supply and data wires must not be interchanged. The transparent connector allows for a visual check of the cable colour codes, ensuring that the open end of the cable is correctly configured. When using patch cables, neighbouring wires on Pins Pin 1/2, 3/4, 5/6 and 7/8 are *usually* (but not always) twisted together. Neighbouring wires *usually* have the same colour, though one of the pair has a colour alternating with white.



Connector with pin numbers, tab down



Open ended patch cable

⁵ Chapter 2.7.2.2.7.2, www.fai.org/gliding/gnss/tech_spec_gnss.pdf

⁶ FLARM uses pin numbering in-line with IGC specifications. The numbering is in reverse order.

⁷ When using FLARM Hardware Version 1 a Jumper links Pins 12 and 14 on the PCB. Units delivered ex-works have this jumper already installed.

⁸ In the case of the cables supplied since March 2005 bearing the legend BLACK BOX on cable and connector, the connections are *usually* as follows: **GND = orange / orange-white**, **+12V = brown / white-brown**. It is necessary to check the polarity prior to connection. When supplying two or more units, only one single cable will be supplied, to be cut in half.

In normal configuration Pin 5 transmits the most important NMEA-0183 Version 2.0 compatible GPGGA and GPRMC codes at a configurable data rate (see document 'Data Port Specifications'); from Hardware version 2 also Garmin proprietary PGRMZ codes with barometric altitude information. Further codes are provided for third party applications (e.g. external displays). These are described in a separate document 'Data Port Specifications'. This document also describes how FLARM software may be configured. A PC application exists for this.

After switching on and the self-test routine, the unit must first capture satellite signals to establish position. Even if the antenna has a clear view of the sky, this process can take a few minutes. For this reason a glider tow / tug pilot should leave FLARM switched on during brief waiting periods between flights or the installations should have a separate wiring and circuit breaker; ensure the aircraft type configuration in FLARM is set appropriately for tug / tow planes, otherwise the warning priority might be compromised.

The installation must be such that FLARM can be switched off during night flights.

Only the power/data socket to the unit may be used for updating FLARM software or obstacle data from the PC. During this process FLARM must be disconnected from other equipment.

8. Extension

Six or 4-pole connectors may be inserted in the 6-pole RJ12 socket. The connections to the pins are the same as for Pins 2 and 7 described above. This socket is intended for use by third party applications (e.g. for an external display via an uncrossed cable) and is regulated by a constant 4.8 kBaud. This socket must neither be used for power supply nor for PC-communication (update, download, configuration).

This socket is not provided in Hardware Version 1; the power/data socket with an 8- (or if necessary 6-) pole Y-intermediate connector should be used for external applications. In this case all third party applications have access to only one single data rate, but which may be configured. Details can be found in the document 'Data Port Specifications'.



9. GPS

The external GPS antenna supplied with the unit must be connected; FLARM will not operate without an adequate GPS signal. The cable length of the 50Ω RG-174U cable with MCX connector is about 2.5 m; cables of other length are not available from FLARM Technology. A specialist must undertake any shortening of the cable, which must never be cut to less than 0.5 m. Antenna splitters must not be used.

The antenna should be horizontal in straight flight and have a generally unobstructed view of the sky, including during turns. The antenna should not have any electrically conducting surfaces (e.g. metal, carbon fibre) above or immediately *alongside*. Ideally, the antenna will be located on top of the instrument panel. Electrically conducting sheet metal under the antenna may enhance its performance. Do not mount the antenna below or inside the instrument panel.

The antenna base contains magnets, but nevertheless requires additional attachments. The antenna must under no circumstances interfere with correct compass operation. If the antenna interferes with the compass, the magnets in the antenna base must be removed with a screwdriver and the metallic foil put back. The antenna does not work without the metallic foil.

If the aircraft is fitted with two or more GPS antennae, they should be separated if possible by at least 25 cm; the same holds good for FLARM radio antennae.



10. Radio Antenna

The middle of the housing upper face has an aperture onto which is screwed an 86 mm long internal $\lambda/4$ radio antenna onto a conventional SMA connector. The antenna must be fitted and removed with care. This antenna is required for operation of FLARM, and the correct installation has a considerable effect upon range for transmitter/receiver range, so the installation must be carefully considered. The antenna must be vertical, allowing generally unobstructed radiation to the front and sides. Do not mount the antenna below or inside the instrument panel. It is theoretically possible to use an inverted installation, but only when making exclusive use of an external display. Horizontal or inclined installation is not acceptable. In particular, there should be no electrically conducting surfaces (metal, carbon fibre) above or immediately alongside the antenna. The antenna must not be under stress or bent, e.g. by the cockpit canopy). When using FLARM in an environment with known static discharges we recommend applying a black heat shrink tube around the full length of the RF-antenna to protect the sensitive receiver.

FLARM Technology can supply alternative external dipole antennas with 1.0m and 2.5m feed cables, dedicated 12mm adapters, antennas for external installation and antenna extension cables (50 Ω RG-174U on conventional SMA). No antennae or cables may be used other than those listed above. An external antenna must be adequately earthed to the airframe. Installation may only be in a Zone 2A or 3 as described in DO-160E Section 23.

11. Sound Signal

The housing upper face has a number of holes to improve the transmission of sound from the internal emitter to the cockpit. These holes must remain unobstructed. There is no intercom connector. Third-party manufacturers have suitable intercom equipment that is compatible with FLARM.



12. Limitations

FLARM is designed and built as a non-essential 'situation awareness only' unit to only support the pilot, and cannot always provide reliable warnings. In particular, FLARM does not give any guidance on avoiding action. Under no circumstances should a pilot or crewmember adopt different tactics or deviate from the normal principles of safe airmanship. Even with FLARM installed, you remain responsible for flying the aircraft and ensure the safety of passengers and other traffic. The use of FLARM is solely at the discretion of the commander and his crew. Operation must be preceded by thorough familiarisation by the commander or his delegated crewmember with the Operating Manual.

FLARM can only warn the pilot of the presence of other aircraft that are also fitted with FLARM or compatible equipment, or warn of obstacles that are stored in the internal data bank. FLARM does *not* communicate with Mode A/C/S transponders, and remains undetected by ACAS/TCAS/TPAS or Air Traffic Control systems. Likewise, FLARM does not communicate with TIS-B, FIS-B or ADS-B.

At present FLARM is not certified by the Civil Aviation Authorities and has not been tested in accordance with the normal aviation requirements (e.g. DO-160E). FLARM software development is largely comparable with Level E of DO-178B; in other words a failure of the unit should have no effect upon aircraft operation and does not increase crew workload. The FLARM obstacle data bank is not certified.

Air band radio frequency allocation and licensing conditions may vary from country to country. The aircraft commander is solely responsible for ensuring that FLARM is operated in conformity with the respective licensing conditions. No licence is required to operate FLARM in Switzerland.

Operation of FLARM is forbidden in the USA or Canada or in aircraft registered in the USA or Canada.

FLARM Technology its associates, development team, suppliers, manufacturers and data suppliers accept no responsibility for any damage or claims that may arise from use of FLARM.

13. Technical Data

The following data are provided without guarantee and may be altered at any time without notice. The warranty period end at latest 6 months after the purchase, but with immediate effect in the case of the following cases: any opening of the box, inappropriate operations or installation (see the restrictions in the Operating and Installation Manual) and intellectual property violations.

Height:	25 mm housing (without internal radio antenna) 100 mm overall height (with internal radio antenna)
Width:	75 mm
Length:	111 mm housing (without cable connectors) 119 mm overall length (with push-buttons, without cable connectors, without IGC/ENL)
Weight:	125 g (with internal radio antenna, without cable, without GPS antenna)
Power supply:	external power supply 8.0 to 26.0 (peak voltage up to 28.0) V DC via RJ45, recommended value 12 V DC, direct galvanic link to aircraft battery via an essential 500 mA circuit breaker; this must be separate from other essential aircraft power systems FLARM has reverse polarity protection.
Power drain:	typically approx. 55 mA at 12 V DC, approx. 37 mA at 24 V DC (Normal operation without warnings or external display), a collision warning may double these values.
Serial Data:	bi-directional RS232, compatible with NMEA-0183 Version 2.0, standard message format GPRMC, GPGGA, data rate 4.8 to 57.6 kBaud, additional NMEA proprietary sentences PFLA and PGRMZ (described in a separate document)
GPS:	16-Channel WAAS/EGNOS compatible GPS engine, external 50Ω active antenna with 2.5m RG-174U cable, MCX connector, 3.3V, dimensions depending upon the antenna used, usually rectangular 45x45 to 50x50 mm, oval or circular of approx. 12 mm thickness.
Radio:	GPS-controlled automatic frequency tuning: 868 – 926 MHz less than 1 % Duty Cycle, Peak Pulse Power 10 mW (ERP), internal λ/4 antenna (screw-fitted to conventional SMA connector), Range approx 2 km, possibly up to 5 km, depending upon antenna and installation
Temperature:	Operation: -10 to +60 °C, storage: -20 to +70 °C, no certification in accordance with DO-160E Sections 4 and 5
Intercom:	not provided, suitable third party units are available
Vibration:	Use in conditions of strong vibration or turbulence should be avoided or subsequently checked prior to continued operation, no certification in accordance with DO-160E Section 8
Country of Origin:	Switzerland, Harmonized System Customs Code 852610



DECLARATION OF CONFORMITY

FLARM Technology GmbH, Haldenstrasse 1, CH-6340 Baar, declares that in typical configuration the 'FLARM Anti-Collision Warning Unit' Hardware Versions 1 to 3 meets the requirements of the CE Mark.

The radio conforms with the requirements of EN 300 220-3:2000 (Power Class 9). The EMC conforms with EN 301 489-3:2002-08 for a Class 3 SRD Device (equipment type I). FLARM is a Class 1 item of radio equipment as defined by R&TTE Directive. The necessary tests and certification were undertaken by Ascom Systec AG (now ADAXYS SA), Hombrechtikon, Switzerland.

These documents may be inspected at the premises of FLARM Technology by arrangement through: info@flarm.com

Zürich, March 2005